

# Comlight Commissioning Service

**Comlight Commissioning Service** sets the installed sensors in operation by programming neighbor setup, light levels, hold times and the number of lights ahead of slow- and fast-moving traffic.

All Comlight light controllers as factory-set to Service Mode, meaning that light levels are set at 100% (no dimming) and that motion detection dimming is not operational before commissioning has been completed. After the installation has been programmed, last step is to take the controllers out of Service Mode, after which the dimming operation is functional.

- Planning** Support the customer in the planning phase of the installation, including recommending parameters for the installation
- Support** Provides installation support for the customer/installer over phone
- Commissioning** On basis of list of installed serial numbers in correct sequence, commission the installation with neighbor setup, id's in sequence, parameters etc. Finalizing step in commissioning process is to take units out of Service Mode. The process can be performed remotely (over gateway, requires Comlight Access subscription), or on-site (requires radio dongle).
- Verification** Verification of street segment either remotely or on-site.



Article No	Description
800-0001	Product and commissioning training per day
800-0002	Commissioning support off-site per installation
800-0004	Commissioning or support on-site per hour
800-0004	Commissioning or support on-site per hour
800-0005	Commissioning or support on-site per day